

HempWood® Cabinet Instructions

Included

- (2) panels
- (1) door frame
- (2) door hinges
- (2) trim pieces
- (1) shelf piece
- (2) backing trim pieces
- (4) shelving prongs
- (4) acrylic holders (optional)
- (1) piece of acrylic (optional)

Instructions

1. If desired dimensions of cabinet are 26x22x14":
 - a. Cut panel (1) panel into 26" and 22" (equal to 48")
 - b. Cut panel (1) panel into 26" and 22" (equal to 48")
 - c. Cut 45° angles on all ends of the panels.
 - d. The 26" panels are the vertical sides and the 22" panels are the horizontal sides.
2. Align panel pieces and secure with wood glue.
 - a. We suggest using Titebond III wood glue.
3. After securing with wood glue, add nails.
 - a. We suggest to using a nail gun as opposed to nailing with a hammer.
 - b. We used 1-3/16" 18-gauge nails.
4. Now that the box is assembled, trim.
 - a. Cut trim pieces to the same dimensions of the box.
 - b. Cut 45° angles on the ends.
 - c. Align front trim pieces on the front of the box and secure with wood glue.
 - d. Pro tip: align the angles of the box with the angles of the trim for proper placement.
 - e. Then, secure with nails.
5. After assembling the box and attaching the front trim, look for any exposed nail heads.
 - a. Hammer in exposed nail heads.
 - b. Use pliers to cut heads that cannot be hammered.
6. Wood fill all seams, nail head holes, and cracks with wood fill.
 - a. We suggest Minwax Sustainable Wood Fill.
 - b. Allow wood fill to dry.
7. After wood has dried, sand to make even.
 - a. We suggest using 120 grit sandpaper.
8. Stain
 - a. We prefer Minwax stains.
9. Now for the door, align the hinges onto the front trim pieces of the box.

- a. After aligning the hinges, predrill onto to front trim piece and door frame.
 - b. Secure hinges to door frame.
 - c. Secure hinges to front trim pieces.
10. For the backing, secure a white trim piece to the top on the inside of the box.
 - a. This is for hanging the cabinet on the wall.
 - b. If you feel the need for additional support, there is another trim piece for placing on the bottom on the inside.
 11. For the shelving, locate desired height of shelf and drill holes for shelving prongs.
 - a. Make sure to NOT drill all the way through the sides of the box.
 12. Place the shelf on top of the prongs.
 13. If you have an acrylic door, the clear acrylic holders will need to be attached to the door frame on the inside.
 14. After attaching acrylic holders, place the acrylic onto the inside of the door frame and turn the holders. Make sure to secure.